

WKP-P

Rectangular
fire damper

Installation manual




SMAY™

Version 6.15

SMAY reserves the right to make changes to this document.

TABLE OF CONTENT

| | |
|--|----|
| INSTALLATION TECHNOLOGY..... | 2 |
| 1. INSTALATION TECHNOLOGY – RIGID WALL | 3 |
| 1.1. PROMADUCT | 6 |
| 2. INSTALLATION TECHNOLOGY – STRUCTURES THICKER THAN 125 MM..... | 7 |
| 3. INSTALLATION TECHNOLOGY – FLEXIBLE WALL WITH 125 MM THICKNESS | 8 |
| 4. INSTALLATION TECHNOLOGY – MKW HONEYCOMB MESH COVER | 10 |



INSTALLATION TECHNOLOGY

Before installing the fire dampers, make sure that there are no damage, during transport or storage, that could block the baffle.

Check that the baffle can be opened and closed (full opening and closing position). To open fire dampers WKP-p use the actuator key.

The opening and closing must proceed smoothly (not stepwise).

Do not pull by baffle to open or close fire damper, it may cause permanent damage, not covered by the warranty.

Before installation verify dimensions of a gap between bottom blade and inner part of housing under blade, and between top blade and inner part of housing above blade. The dimension of the gap can not be lower than 4 mm.

Before installing, secure the fire damper, by dust and dirt, using a foil or other screening material. It can prevent components of fire damper by damage.

Dampers to preserve of the declared resistance, insulation and smoke leakage EIS120, EIS90, should be installed on wall, which was classified as EIS120, EIS90.

It is allowed to install WKP-P dampers in wall with other fire-resistance, should be remembered that fire-resistance in this situation is resistance of lowest classified (in this regard) element in this system.

Ducts made of flammable and non-flammable materials can be connected to the damper. Ducts should be installed that they cannot load the damper during fire. Ducts lengthening during fire can be compensated by support and knee.

ATTENTION: Distance between fire dampers or fire damper and construction elements must be compatible with standard 1366-2:

- a. Minimal 200 mm between fire damper, which are installed in different ventilating wires,
- b. Minimal 75 mm between fire damper and construction element (wall/ceiling).

1. INSTALATION TECHNOLOGY – RIGID WALL

- Make an opening in the wall 246 mm greater than the dimension B and 120 mm greater than heigh H, this is $B+246$ and $H+120$.
- For the dampers which have height $H=200$ mm and $H=300$ mm installation opening should have height $H+160$ [mm] (acceptable $140\div 180$ [mm]).
- Put the closed fire damper into the installation opening and support or suspend, in this way that an axis of the fire baffle matches the axis of the wall, and ensure a concentricity of fire damper and installation opening.
- After setting the fire damper as described, fill the gap between the fire damper and the wall with cement, cement-lime mortar or concrete.
- After drying of the mortar (approx. 48 hours), remove used supports or suspensions, check the fire damper correct operation and leave it in fully open position.




Figure 1. Dimensions of the installation opening of the WKP-P dampers in rigid wall with a horizontal and with vertical axis of rotation of the baffle. The C dimension is given in the table.

| H | C |
|-----|-----|
| 200 | 0 |
| 300 | 100 |
| 400 | 100 |
| 500 | 200 |
| 600 | 200 |
| 700 | 300 |
| 800 | 300 |

H – nominal height of the damper




Figure 2. Installing method of WKP-P fire dampers in rigid wall, baffle axis should be in line with wall axis




Figure 3. Installing method of WKP-P fire dampers in rigid wall, baffle axis should be in line with wall axis




Figure 4. Installing method of WKP-P fire dampers in rigid wall

1.1.PROMADUCT

After setting the fire damper as described, and build it in wall, duct made of PROMATECT-L500 boards with 50 mm thickness must be installed. The band around the duct must be made by PROMATECT-L500, with 50 mm thickness and 60 mm width. Connection of damper and the wall, and damper with the band must be made by K84 glue. The sides of the duct and the band must be connected by using 4,2x90 – 4,8x120 screws.




Figure 5.Installing method of WKP-P fire dampers with PROMAT boards duct

2. INSTALLATION TECHNOLOGY – STRUCTURES THICKER THAN 125 mm

In rigid walls, with thickness less than or equal to 125 mm, WKP-P fire dampers are installed in this way that an axis of the fire baffle matches the axis of the wall, and ensure a concentricity of fire damper and installation opening.

In case when wall have more than 125 mm thickness: WKP-P fire dampers are installed in this way that the damper border is flush with the wall surface (Fig. 6).




Figure 6. Installation method of fire dampers WKP-P in structures thicker than 125 mm

3. INSTALLATION TECHNOLOGY – FLEXIBLE WALL WITH 125 mm THICKNESS

- Make an opening in the wall with the dimensions 310 mm greater than the width B and 180 mm greater than the height H: this is $B+310$ and $H+180$.
- For the dampers which have height $H=200$ mm and $H=300$ mm installation opening should have height $H+160$ [mm] (acceptable $140\div 180$ [mm]).
- Make a frame of two layers of GKF boards 15 mm thick and a width corresponding to the installation opening screwed tightly, bearing in mind the exact sealing at their joints by using Hilti Firestop Coating CP 673, Promastop-Coating, Promaseal-Mastic or Soudal Firesilicone B1 FR.
- Put the closed fire damper into the installation opening and support or suspend, in this way that an axis of the fire baffle matches the axis of the wall, and ensure a concentricity of fire damper and installation opening.
- After setting the fire damper as described, fill the gap between the fire damper and the wall with non-flammable mineral wool of high density, 100 kg/m³ or more.
- Seal the place of filling with mineral wool using the sealing mass given in pts.2
- Mount the collar, of GKF boards on both side of wall, with a thickness of 15 mm and a width of 150 mm, with the screws.
- After mounting the collar, remove the supports or suspensions, check the fire damper correct operation and leave it in open position.




Figure 7. Installation method of fire dampers WKP-P in flexible wall with 125 mm thick




Figure 8. Installation method of fire dampers WKP-P in flexible wall

4. INSTALLATION TECHNOLOGY – MKW HONEYCOMB MESH COVER

- Before installing honeycomb mesh cover, it is necessary to stick 5x10 self-adhesive ceramic gasket, on inside surface of mesh cover, along the deflection, around the perimeter.
- Honeycomb mesh cover install to the wall with use metal pins for gas-concrete 6x32 and with use 5x40 screws.
- Honeycomb mesh cover install in this way as shown in the figure below. Outer edges of openings on left side of mesh cover as well on a top and on a bottom must be in line with inside edges of the damper.




Figure 9. Installation method of MKW-B honeycomb mesh cover




Figure 10. Installation method of MKW-D honeycomb mesh cover




Figure 11. Installation method of KST grille